



Center the sign on the counterweight then mark the hole location through the sign preferably with a center punch. Use a #7 bit to drill the holes then thread them using a ¼-20 NC tap. Secure the sign with the provided stainless button head cap screws.